# **T-SENSE FMI**

# The THz imager for material inspection



#### Your products deserve maximum efficiency

HÜBNER Photonics has developed a new innovative measuring system: The Terahertz Imager T-SENSE FMI.

This highly efficient technology is based on the most recent research results. Production can be monitored and controlled at various levels. T-SENSE FMI uses millimeter waves in the lower terahertz range with no health risks involved and known from the newest Bodyscanners at airports. This means that the equipment can be used anywhere and for several purposes without the need for radiation protection.

T-SENSE FMI can visualize process-related properties that are normally remain hidden to your eyes.



# HÜBNER Photonics | Coherence matters.

# **T-SENSE FMI**

#### **Areas of application**

- Impurities visible through packaging
- Monitoring of a fill-level
- Monitoring of the bonding process
- Monitoring of the drying process
- Detecting shrinkage or cavities in non-metallic materials
- Inspecting frozen food
- Identifying flaws and cavities in non-electrically conductive components

#### **User-friendly**

The stand-alone system is ready for use straight after set-up and start. Only a main connection is necessary. Simple and intuitive application software provides the device to be used with easy instruction.

#### Individually adaptable

The innovative measuring system can be specifically adapted to your production. We will be pleased to develop a tailormade solution for your measuring requirements, including an individually adapted software solution for your specific needs. Your aim is our aim: a zero-defect production.



T-SENSE FMI Grafic user interface with different filters side by side. All parameters are intuitively customizable. There is also an image overlay technique of the visual and the THz image

#### **Operation Principle**

Terahertz waves essentially stand for the frequency range of the electromagnetic spectrum, ranging between 0.1 THz and 10 THz. Numerous nonconductive materials such as plastics, compounds, ceramics, paper or clothing appear almost transparent on THz frequencies. The T-SENSE FMI makes use of the varying absorption levels of the objects being illuminated.

In addition, it measures the time range of the signal being emitted. It can recognize the smallest difference, regardless of whether this is due to varying levels of moisture or a deliberate or accidental alteration of the composition of the product in question.



#### **Frequency range**

Approx. 90 GHz

Analysis of amplitude and phase

## Maximum dimensions of scanned objects

Width	270 mm
Height	50 mm



#### Surroundings & electrical supply

Operating temperature range	10 - 45 °C
Power supply	100 - 230 VAC
Power consumption	150 W
Frequency	50 - 60 Hz

#### **Dimensions & weight**

Length	1370 mm
Width	590 mm
Height	660 mm
Weight	100 kg

## Visualizing the invisible without any risk to human health.





### **Headquarters**

HÜBNER Photonics HÜBNER GmbH & Co. KG Heinrich-Hertz Strasse 2, 34123 Kassel, Germany

 Phone:
 +49 561 998 0

 Fax:
 +49 561 998 1515

 E-mail:
 photonics@hubner-germany.com

www.hubner-photonics.com

**Cobolt AB** Vretenvägen 13, SE-171 54 Solna, Sweden

 Phone:
 +46 8 545 912 30

 Fax:
 +46 8 545 912 31

 E-mail:
 info@coboltlasers.com

www.coboltlasers.com



# **Direct sales offices**

HUBNER Photonics Inc 2635 North First Street, Suite 228, San José, California, 95134, USA

Phone: +1(408)708 4351 Fax: +1(408)490 2774 E-mail: info.usa@hubner-photonics.com

#### HÜBNER Photonics UK

Royal Mail House, Terminus Terrace, Southampton, Hampshire, SO14 3FD

Phone: +44 2380 438701

E-mail: info.uk@hubner-photonics.com